

V7E/LX7-COP6

V7E Option Switch Settings: 1(Pulse/ICT104U/MDB/RS232 A0)

Supported bill Col\$ 2000, 5000, 10000, 20000, 50000, 100000 6bills.

V7E dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	
★ Reject Col\$ 2000	ON												
★ Accept Col\$ 2000	OFF												
Reject Col\$ 5000		ON											
★ Accept Col\$ 5000		OFF											
Reject Col\$ 10000			ON										
★ Accept Col\$ 10000			OFF										
Reject Col\$ 20000				ON									
★ Accept Col\$ 20000				OFF									
Reject Col\$ 50000 & 100000					ON								
★ Accept Col\$ 50000 & 100000					OFF								
Reserved						ON							
★ Reserved						OFF							
Pulse Mode	Other Mode												
Harness Disable	BA stops working when fishing						ON						
★ Harness Enable	Normal						OFF						
Inhibit Active High							ON						
★ Inhibit Active Low							OFF						
★ 1 pulse / Col\$ 1000								OFF	OFF				
2 pulses / Col\$ 1000								ON	OFF				
4 pulses / Col\$ 1000								OFF	ON				
20 pulses / Col\$ 1000								ON	ON				
★ Pulse Speed	50ms LO / 50ms HI								OFF	OFF			
	60ms LO / 300ms HI								ON	OFF			
	30ms LO / 50ms HI								OFF	ON			
	150ms LO / 150ms HI								ON	ON			

★ Manufacture setting

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "SW1" setting.)

Appendix

V7E/LX7-COP6(Pulse/ICT104U/MDB/RS232 A0)

DIP SWITCHES SETTING: 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ICT104U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
Reserved				ON
★				OFF

DIP SWITCHES SETTING: 2(ICT104U)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
Reserved				ON
★				OFF

DIP SWITCHES SETTING: 2(MDB) Currency Assign Data

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 10 Decimal Point Position (DPP) = 1	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
ICT104U Interface		OFF	ON	
★ MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
Reserved				ON
★				OFF

Interface Bill value	Pulse	ICT104U	RS232 A0	MDB
BV1				
BV2	Col\$ 2000	Col\$ 2000	Col\$ 2000	Col\$ 2000
BV3	Col\$ 5000	Col\$ 5000	Col\$ 5000	Col\$ 5000
BV4	Col\$ 10000	Col\$ 10000	Col\$ 10000	Col\$ 10000
BV5	Col\$ 20000	Col\$ 20000	Col\$ 20000	Col\$ 20000
BV6	Col\$ 50000	Col\$ 50000	Col\$ 50000	Col\$ 50000
BV7	Col\$100000	Col\$100000	Col\$100000	Col\$100000

★ Manufacture setting

DIP SWITCHES SETTING: 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON	OFF	
ICT104U Interface		OFF	ON	
MDB Interface		ON	ON	
★ RS232 A0 Mode		OFF	OFF	
Reserved				ON
★				OFF

RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	Reserved
2	Col\$ 2000
3	Col\$ 5000
4	Col\$ 10000
5	Col\$ 20000
6	Col\$ 50000
7	Col\$100000
8	Reserved
9	Reserved

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "SW1" setting.)